

6. Tone List

No.	Name	MSB	LSB	PC
Piano				
1	Concert Piano	0	68	1
2	Ballade Piano	16	67	1
3	Bright Piano	8	66	2
4	Magical Piano	47	65	3
5	Piano + Strings	25	64	1
6	Piano + Pad	47	64	3
7	Piano + Choir	26	64	1
8	Rock Piano	8	64	3
9	Ragtime Piano	0	64	4
10	Harpsichord	0	66	7
11	Coupled Harpsichord	8	66	7
Other				
1	Trem. TineEP	0	64	5
2	Pop E.Piano	16	67	5
3	Tine EP	0	66	5
4	FM E.Piano	0	70	6
5	Bright FM EP	0	64	6
6	Vib. ReedEP	24	69	5
7	Clav.	0	67	8
8	PhaserTineEP	0	71	5
9	Vibraphone	0	0	12
10	Marimba	0	64	13
11	Celesta	0	0	9
12	Mallet Isle	0	64	115
13	Morning Lite	0	68	99
14	SymphonicStr	1	67	50
15	Rich Strings	0	71	50
16	OrchestraStr	0	64	49
17	DecayStrings	1	65	50
18	Harp	0	68	47
19	PizzicatoStr	0	0	46
20	ChurchOrgan1	0	66	20
21	ChurchOrgan2	8	69	20
22	Combo Jz.Org	0	70	19
23	Ballad Organ	0	69	19
24	Full Stops	0	69	17
25	Mellow Bars	32	68	17
26	Accordion	0	68	22
27	Aerial Choir	8	64	53
28	Jazz Scat	0	65	55
29	Female Aahs	8	66	53
30	Male Aahs	8	68	53
31	Decay Choir	1	64	53
32	Thum Voice	0	66	54
33	Soft Pad	0	64	90
34	Dcy ChoirPad	1	66	90
35	Nylon-str.Gt	0	0	25
36	Steel-str.Gt	0	0	26
37	Jazz Guitar	0	64	27
38	AcousticBass	0	71	33
39	A.Bass+Cymb1	0	66	33
40	FingeredBass	0	0	34
GM2				
41	STANDARD Set	120	0	1

No.	Name	MSB	LSB	PC
42	ROOM Set	120	0	9
43	POWER Set	120	0	17
44	ELEC.Set	120	0	25
45	ANALOG Set	120	0	26
46	JAZZ Set	120	0	33
47	BRUSH Set	120	0	41
48	ORCH.Set	120	0	49
49	SFX Set	120	0	57
50	Piano 1	121	0	1
51	Piano 1w	121	1	1
52	Piano 1d	121	2	1
53	Piano 2	121	0	2
54	Piano 2w	121	1	2
55	Piano 3	121	0	3
56	Piano 3w	121	1	3
57	Honky-tonk	121	0	4
58	Honky-tonk w	121	1	4
59	E.Piano 1	121	0	5
60	Detuned EP 1	121	1	5
61	Vintage EP	121	2	5
62	'60s E.Piano	121	3	5
63	E.Piano 2	121	0	6
64	Detuned EP 2	121	1	6
65	St.FM EP	121	2	6
66	EP Legend	121	3	6
67	EP Phase	121	4	6
68	Harpsi.	121	0	7
69	Coupled Hps.	121	1	7
70	Harpsi.w	121	2	7
71	Harpsi.o	121	3	7
72	Clav.	121	0	8
73	Pulse Clav.	121	1	8
74	Celesta	121	0	9
75	Glockenspiel	121	0	10
76	Music Box	121	0	11
77	Vibraphone	121	0	12
78	Vibraphone w	121	1	12
79	Marimba	121	0	13
80	Marimba w	121	1	13
81	Xylophone	121	0	14
82	TubularBells	121	0	15
83	Church Bell	121	1	15
84	Carillon	121	2	15
85	Santur	121	0	16
86	Organ 1	121	0	17
87	TremoloOrgan	121	1	17
88	'60s Organ	121	2	17
89	Organ 2	121	3	17
90	Perc.Organ 1	121	0	18
91	Chorus Organ	121	1	18
92	Perc.Organ 2	121	2	18
93	Rock Organ	121	0	19
94	Church Org.1	121	0	20
95	Church Org.2	121	1	20
96	Church Org.3	121	2	20
97	Reed Organ	121	0	21

MIDI Implementation

No.	Name	MSB	LSB	PC
98	Puff Organ	121	1	21
99	Accordion 1	121	0	22
100	Accordion 2	121	1	22
101	Harmonica	121	0	23
102	Bandoneon	121	0	24
103	Nylon-str.Gt	121	0	25
104	Ukulele	121	1	25
105	Nylon Gt o	121	2	25
106	Nylon Gt 2	121	3	25
107	Steel-str.Gt	121	0	26
108	12-str.Gt	121	1	26
109	Mandolin	121	2	26
110	Steel+Body	121	3	26
111	Jazz Guitar	121	0	27
112	Hawaiian Gt	121	1	27
113	Clean Guitar	121	0	28
114	Chorus Gt 1	121	1	28
115	Mid Tone Gt	121	2	28
116	Muted Guitar	121	0	29
117	Funk Guitar1	121	1	29
118	Funk Guitar2	121	2	29
119	Chorus Gt 2	121	3	29
120	Overdrive Gt	121	0	30
121	Guitar Pinch	121	1	30
122	DistortionGt	121	0	31
123	Gt Feedback1	121	1	31
124	Dist.Rtm Gt	121	2	31
125	Gt Harmonics	121	0	32
126	Gt Feedback2	121	1	32
127	AcousticBass	121	0	33
128	FingeredBass	121	0	34
129	Finger Slap	121	1	34
130	Picked Bass	121	0	35
131	FretlessBass	121	0	36
132	Slap Bass 1	121	0	37
133	Slap Bass 2	121	0	38
134	Synth Bass 1	121	0	39
135	WarmSyn.Bass	121	1	39
136	Synth Bass 3	121	2	39
137	Clav.Bass	121	3	39
138	Hammer	121	4	39
139	Synth Bass 2	121	0	40
140	Synth Bass 4	121	1	40
141	RubberSyn.Bs	121	2	40
142	Attack Pulse	121	3	40
143	Violin	121	0	41
144	Slow Violin	121	1	41
145	Viola	121	0	42
146	Cello	121	0	43
147	Contrabass	121	0	44
148	Tremolo Str.	121	0	45
149	PizzicatoStr	121	0	46
150	Harp	121	0	47
151	Yang Qin	121	1	47
152	Timpani	121	0	48
153	Strings	121	0	49

No.	Name	MSB	LSB	PC
154	Orchestra	121	1	49
155	'60s Strings	121	2	49
156	Slow Strings	121	0	50
157	Syn.Strings1	121	0	51
158	Syn.Strings3	121	1	51
159	Syn.Strings2	121	0	52
160	Choir 1	121	0	53
161	Choir 2	121	1	53
162	Voice	121	0	54
163	Humming	121	1	54
164	Synth Voice	121	0	55
165	Analog Voice	121	1	55
166	OrchestraHit	121	0	56
167	Bass Hit	121	1	56
168	6th Hit	121	2	56
169	Euro Hit	121	3	56
170	Trumpet	121	0	57
171	Dark Trumpet	121	1	57
172	Trombone 1	121	0	58
173	Trombone 2	121	1	58
174	Bright Tb	121	2	58
175	Tuba	121	0	59
176	MuteTrumpet1	121	0	60
177	MuteTrumpet2	121	1	60
178	French Horn1	121	0	61
179	French Horn2	121	1	61
180	Brass 1	121	0	62
181	Brass 2	121	1	62
182	Synth Brass1	121	0	63
183	Synth Brass3	121	1	63
184	AnalogBrass1	121	2	63
185	Jump Brass	121	3	63
186	Synth Brass2	121	0	64
187	Synth Brass4	121	1	64
188	AnalogBrass2	121	2	64
189	Soprano Sax	121	0	65
190	Alto Sax	121	0	66
191	Tenor Sax	121	0	67
192	Baritone Sax	121	0	68
193	Oboe	121	0	69
194	English Horn	121	0	70
195	Bassoon	121	0	71
196	Clarinet	121	0	72
197	Piccolo	121	0	73
198	Flute	121	0	74
199	Recorder	121	0	75
200	Pan Flute	121	0	76
201	Bottle Blow	121	0	77
202	Shakuhachi	121	0	78
203	Whistle	121	0	79
204	Ocarina	121	0	80
205	Square Lead1	121	0	81
206	Square Lead2	121	1	81
207	Sine Lead	121	2	81
208	Saw Lead 1	121	0	82
209	Saw Lead 2	121	1	82

No.	Name	MSB	LSB	PC
210	Doctor Solo	121	2	82
211	Natural Lead	121	3	82
212	SequencedSaw	121	4	82
213	Syn.Calliope	121	0	83
214	Chiffer Lead	121	0	84
215	Charang	121	0	85
216	Wire Lead	121	1	85
217	Solo Vox	121	0	86
218	5th Saw Lead	121	0	87
219	Bass+Lead	121	0	88
220	Delayed Lead	121	1	88
221	Fantasia	121	0	89
222	Warm Pad	121	0	90
223	Sine Pad	121	1	90
224	Polysynth	121	0	91
225	Space Voice	121	0	92
226	Itopia	121	1	92
227	Bowed Glass	121	0	93
228	Metallic Pad	121	0	94
229	Halo Pad	121	0	95
230	Sweep Pad	121	0	96
231	Ice Rain	121	0	97
232	Soundtrack	121	0	98
233	Crystal	121	0	99
234	Synth Mallet	121	1	99
235	Atmosphere	121	0	100
236	Brightness	121	0	101
237	Goblins	121	0	102
238	Echo Drops	121	0	103
239	Echo Bell	121	1	103
240	Echo Pan	121	2	103
241	Star Theme	121	0	104
242	Sitar 1	121	0	105
243	Sitar 2	121	1	105
244	Banjo	121	0	106
245	Shamisen	121	0	107
246	Koto	121	0	108
247	Taisho Koto	121	1	108
248	Kalimba	121	0	109
249	Bagpipe	121	0	110
250	Fiddle	121	0	111
251	Shanai	121	0	112
252	Tinkle Bell	121	0	113
253	Agogo	121	0	114
254	Steel Drums	121	0	115
255	Woodblock	121	0	116
256	Castanets	121	1	116
257	Taiko	121	0	117
258	Concert BD	121	1	117
259	Melodic Tom1	121	0	118
260	Melodic Tom2	121	1	118
261	Synth Drum	121	0	119
262	TR-808 Tom	121	1	119
263	Elec.Perc.	121	2	119
264	Reverse Cym.	121	0	120
265	Gt FretNoise	121	0	121

No.	Name	MSB	LSB	PC
266	Gt Cut Noise	121	1	121
267	BsStringSlap	121	2	121
268	Breath Noise	121	0	122
269	Fl.Key Click	121	1	122
270	Seashore	121	0	123
271	Rain	121	1	123
272	Thunder	121	2	123
273	Wind	121	3	123
274	Stream	121	4	123
275	Bubble	121	5	123
276	Bird 1	121	0	124
277	Dog	121	1	124
278	Horse Gallop	121	2	124
279	Bird 2	121	3	124
280	Telephone 1	121	0	125
281	Telephone 2	121	1	125
282	DoorCreaking	121	2	125
283	Door	121	3	125
284	Scratch	121	4	125
285	Wind Chimes	121	5	125
286	Helicopter	121	0	126
287	Car Engine	121	1	126
288	Car Stop	121	2	126
289	Car Pass	121	3	126
290	Car Crash	121	4	126
291	Siren	121	5	126
292	Train	121	6	126
293	Jetplane	121	7	126
294	Starship	121	8	126
295	Burst Noise	121	9	126
296	Applause	121	0	127
297	Laughing	121	1	127
298	Screaming	121	2	127
299	Punch	121	3	127
300	Heart Beat	121	4	127
301	Footsteps	121	5	127
302	Gun Shot	121	0	128
303	Machine Gun	121	1	128
304	Laser Gun	121	2	128
305	Explosion	121	3	128