

Compatibility of each piano with the application is as follows.

- Blank indicates it is not supported.
- Requirements vary depending on the connection method and operating system of the mobile device you use.
- Make sure your Roland piano model is updated with the most current system program. The latest system program and setup instructions can be found on the support pages at www.roland.com. (Except for Operating Systems that are not verified to work.)
- To learn about the parameters available in the Roland Piano App, please refer to the "[Function Compatibility Info and Adjustable Parameter List](#)" document.

*iPad Pro 9.7" is not supported.
**Rhythm function is not supported.

| | | Piano Every Day (Discontinued) | Piano Partner Ver.2.0 | Piano Designer |
|-------------------------------|---------|--|---|---|
| CONNECTION METHOD | | Bluetooth® (Hereinafter referred to as "BT".) | 1. Bluetooth® (Hereinafter referred to as "BT".) 2. Wired connection (Hereinafter referred to as "Wired".) - iOS device requires an iPad Camera Connection Kit or Lightning-USB Camera Adaptor. -Android devices require a USB cable. | 1. Bluetooth® (Hereinafter referred to as "BT".) 2. Wireless LAN (Hereinafter referred to as " WLAN ") -A wireless USB Adapter (WNA1100-RL or ONKYO UMF-1, sold separately) and a Wireless LAN access point are required. 3. USB cable (Wired connection) (Hereinafter referred to as "Wired".) -iPad requires a USB cable and an Apple Camera Connection Kit or Lightning USB camera adapter. -Android devices require a USB cable, a USB adapter, and a micro-USB cable. |
| SUPPORTED DEVICES AND OS | iOS | iOS 10.0 or later. iPadOS 10.0 or later. iPod touch iOS 10.0 or later. | iOS 9.3.5 or later. Compatible with iPhone SE or later, iPad (3rd generation or later), iPad Air (1st generation or later), iPad mini (2nd generation or later), iPad Pro 9.7inch (Incompatible with GO:PIANO (GO-61P), GO:PIANO with Alexa Built-in (GO-61P-A)), iPad Pro 11 inch (3rd generation), iPad Pro 12.9 inch, iPod touch (5th generation or later). | iOS 9.3.5 or later. Compatible with iPhone 5S or later, iPad (2nd generation or later), iPad Air (1st generation or later), iPad mini (1st generation or later), iPad Pro 9.7inch, iPad Pro 11 inch (3rd generation), iPad Pro 12.9-inch, iPod touch (5th generation or later). |
| | Android | Android 7.1 or later. Recommended Android tablets (1280 x 768 resolution or higher), Bluetooth 4.0 or later. Note: We cannot guarantee full compatibility with all Android devices that meet the specification requirements. | Android 7.1 or later. Android tablets (1280 x 768 resolution or higher), Bluetooth 4.0 or later (if connecting via Bluetooth). Note: We cannot guarantee full compatibility with all Android devices that meet the specification requirements. | Android 5.1 or later. Note: We cannot fully guarantee compatibility for all devices that support Android OS and specifications requirements. |
| Compatible Products List Page | | N/A | Roland - Piano Partner 2 Version 2.0 iOS/Android App | Roland - Piano Designer iOS/Android App |
| GP-9M | | | | BT |
| GP-9 | | | | BT |
| GP-6 | | | | BT |
| GP-3 | | | | |
| GP609 | | | BT/Wired | BT |
| GP607 | | | BT/Wired | BT |
| LX708 | | BT | | BT |
| LX706 | | BT | | BT |
| LX705 | | BT | | BT |
| LX-17 | | | BT/Wired | BT |
| LX-9 | | | | |
| LX-7 | | | BT/Wired | BT |
| LX-6 | | | | |
| LX-5 | | | | |
| LX-15e | | | | WLAN/Wired |
| HP704 | | BT | | BT |
| HP702 | | BT | | BT |

| | | | |
|--|-----------|--------------------|-------------------|
| HP701 <i>*Available in certain regions only.</i> | BT | | BT |
| HP605 | | BT/Wired | BT |
| HP603A HP603 | | BT/Wired | BT |
| HP601 | | BT/Wired | BT |
| HP508 | | | WLAN/Wired |
| HP506 | | | WLAN/Wired |
| HP504 | | | WLAN/Wired |
| RP701 | BT | | BT |
| RP501R | | BT/Wired | |
| RP107 | | | |
| RP102 | | BT/Wired | |
| KIYOLA KF-10 | | BT/Wired | BT |
| DP603 | | BT/Wired | BT |
| DP90Se | | | WLAN/Wired |
| DP90e | | | WLAN/Wired |
| F-140R | | BT/Wired | |
| F701 | BT | | BT |
| F107 | | | |
| FP-90X | BT | | BT |
| FP-60X | BT | | BT |
| FP-30X | BT | | BT |
| FP-90 | | BT/Wired | BT |
| FP-80 | | | WLAN/Wired |
| FP-60 | | BT/Wired | BT |
| FP-30 | | BT/Wired | |
| FP-10 | | BT/Wired ** | |
| FP-E50 | | | |
| FRP-1 <i>*Available in certain regions only</i> | | | |
| FRP-2-ACR <i>*Available in certain regions only</i> | | | |
| FRP-NUVOLA <i>*Available in certain regions only</i> | | | |
| RCP-800 <i>*Available in certain regions only</i> | BT | | |
| CG-1 <i>*Available in certain regions only</i> | | | |
| CPF-107 <i>*Available in certain regions only</i> | | | |
| CPF-140 <i>*Available in certain regions only</i> | | | |
| MP-200 <i>*Available in certain regions only</i> | | | |
| RP-500 <i>*Available in certain regions only</i> | | | |
| GO:PIANO88 (GO-88PX) | | | |
| GO:PIANO (GO-88P) | | BT/Wired * | |
| GO:PIANO88 (GO-61P) | | BT/Wired ** | |
| GO:PIANO with Alexa Built-in (GO-61P-A) | | BT | |